

Cleaning & Maintenance Guide

ENWORK

To help ensure the quality of your Enwork furniture, please read and adhere to the following.

LAMINATE SURFACES

Spot clean with a soft cloth using non-abrasive, water-based cleaners such as Simple Green (diluted per instructions), Windex, or Fantastik.

- Use a mixture of baking soda and water for hard-to-clean areas and darker laminates with streaking issues.
- To clean Black FENIX® laminate, use a Magic Eraser dipped in warm water. Rub in circles then dry with a clean, non-abrasive cloth.
- To clean off adhesives, use a clean cloth damp with nail polish remover. Wipe clean with a separate cloth damp with water.
- Markerboard laminate should be cleaned with a clean, non-abrasive, damp cloth. A mild soap/water solution or liquid detergent can be used.

PAINTED SURFACES

Spot clean with a soft cloth using non-abrasive, waterbased cleaners such as Simple Green (diluted per instructions) or Fantastik.

DO NOT USE: Solvents, abrasive cleaners, steel wool, powder soap, harsh chemicals, acids, or alkaline on laminate, veneer, and painted surfaces.

VENEER SURFACES

Spot clean with Murphy's Oil Soap and water solution using a slightly damp, soft cloth. Wipe dry as needed to avoid water stains.

CAMBRIA® QUARTZ

Wipe with warm water and use mild soap, if desired. Due to its nonporous nature, Cambria is stain resistant and reduces bacterial growth. Unlike granite, quartz does not require regular sealing, polishing or reconditioning.

CORIAN® SOLID SURFACE

For day-to-day cleaning, warm soapy water, ammonia-based cleaners, or commercially available solid surface cleaners will remove most residues. Rinse and towel dry the surface to prevent spotting.

DO NOT USE: Traditional window cleaners as they can leave a waxy build-up that dulls the surface.

ACRYLIC & FROSTED ACRYLIC

Use a plastic specific cleaner, such as Novus No. 1, or warm water and dish soap with a soft cloth. For a diluted bleach solution, mix 1/3 cup bleach per gallon of water. Use a clean soft cloth and apply only light pressure. Test in an inconspicuous area before use.

WARNING: Acrylic screens scratch and scuff easily. After removing protective film, carefully install the screen.

DO NOT: remove protective film from acrylic screens, then stack them in a pile or against each other. Experience shows this will cause marring and scratching. Do not use: Abrasive cleaners, or cleaners that contain ammonia or alkaline-based product (including household cleaners) that will cause crazing.

KRYSTALCAST®

Use a dish soap and water mix—in a spray bottle—with a Green Scotch Brite 3M scrub pad to clean and loosen all dirt and goo (including oil and wine stains, etc.), then dry with a clean dry towel.

BACK-PAINTED GLASS

Simply wipe with a glass cleaner such as Windex to clean. Glass is susceptible to normal wear and tear. Scratching may be caused by metals, other glass, or similar solid objects. Shallow scratches may be repaired by lightly swirling pumice hand soap (e.g., Gojo Natural Orange) over the scratch with a plastic razorblade or paper towel.

TEXTILES

Use a vacuum on the textile as needed. For deep stains, fabric may be cleaned with mild water-free solvents, water-based cleaning agents, or foam. Test cleaner on an inconspicuous section of fabric before use. For COM textiles, follow manufacturer's cleaning recommendation. High Performance Textiles are bleach cleanable.

ACOUSTIC PET MATERIAL

Cleanable with bleach solution and other disinfectant sprays and cleaners. Test on inconspicuous area before use.